

Чтение руководства

Показывает заголовок руководства.

В этой области отображается заголовок руководства для текущей открытой страницы.

Показывает название главы и название раздела.

В этой области отображается название главы и название раздела для текущей открытой страницы.

Указывает номер главы.

В правой части каждой страницы указан номер главы для текущей открытой страницы.

FX Configurator-FP
Operation Manual

9 Print
9.2 Printing

9.2 Printing

9.2.1 setting the item to print

Printing the positioning parameters, servo parameters and table information.

1 Follow any of the procedures below.

- Click [Print].
- Select [File] → [Print].

The [Print] dialog box appears.

2 Set the item to print.

[Print] dialog box has [Item specification], [Servo parameters] and [table information] tabs. Click the tab to set. For [Servo parameters] and [table information] tabs, refer to the following pages.

1. [Item specification] tab

| Item | Description |
|--------------------|---|
| Axis specification | Specifies the axis data to print |
| All axis | Prints X, Y and XY-axis data |
| Axis specification | Prints the ticked axis data <ul style="list-style-type: none"> X-axis Y-axis XY-axis |
| Print data | Specifies the data type to print |
| All item | Prints [Positioning parameters], [Servo parameters] and [Table information] |
| Item specification | Prints the ticked data item <ul style="list-style-type: none"> Positioning parameters Servo parameters Table information |
| <Printer setting> | Displays [Printer setting] dialog box |
| <Print> | Outputs to printer depending on the specified contents |
| <Print preview> | Displays the print preview |
| <Close> | Closes the dialog box without printing |

→ Refer to Section 9.1.

1 Introduction

2 Initial Setup

3 Window and Operation

4 Creating Files

5 Data set

6 Setting One Description

7 Data Item Procedure

8 Setting Data Item

9 Print

10 Edit Function

1 2 3. →

Указывает этапы процедуры. В данном руководстве меню и пункты выделены скобками.

[] : Относится к параметрам в строках меню, элементах диалоговых окон или FX Configurator-FP служебное меню.

< > : Относится к кнопкам диалогового окна или клавиатура ПК.

Показывает ссылку.

Знак " → " является выражая ссылочное назначение и справочное руководство.

Приведенная выше диаграмма отличается от фактической страницы, так как приведена только для пояснения.